

Company	Part Number	Component Type	Manufacturer	APU Type	Aircraft Type	Scope
Triumph Air Repair	158935-2	VALVE OIL TEMP	ACC	GTCP331	Various	FT
Triumph Air Repair	160176-1	OIL COOLER	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3289504-2	VALVE GEARBOX REGULATING	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3289514-1	VALVE GEARBOX SHUTOFF	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3289618-1	CHAMBER VARIABLE VOLUME	ACC	GTCP331	Various	FT
Triumph Air Repair	3290594-1	CHAMBER VARIABLE VOLUME	ACC	GTCP331	Various	FT
Triumph Air Repair	3614400-1	MODULE FLOW SENSING	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3614400-7	MODULE FLOW SENSING	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3614416-1	FAN ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3614416-2	FAN ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3616959-6	FAN ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3616977-2	FAN ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3790076-105	ACTUATOR IGV	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3862160-9	FAN ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3876023-2	SWITCH OIL TEMPERATURE	ACC	GTCP331	Various	FT
Triumph Air Repair	3876024-4	SWITCH LOW OIL PRESSURE	ACC	GTCP331	Various	FT
Triumph Air Repair	3876024-5	SWITCH LOW OIL PRESSURE	ACC	GTCP331	Various	FT
Triumph Air Repair	3876035-4	SENSOR CPRSR INL PRESS	ACC	GTCP331	Various	FT
Triumph Air Repair	3876035-5	SENSOR CPRSR INL PRESS	ACC	GTCP331	Various	FT
Triumph Air Repair	3876048-3	SWITCH DIFF PRESS GEN	ACC	GTCP331	Various	FT
Triumph Air Repair	3876049-3	SOLENOID FUEL VALVE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3876049-4	VALVE SOLENOID FUEL	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3876059-2	SWITCH OIL LEVEL	ACC	GTCP331	Various	FT
Triumph Air Repair	3876082-4	TRANSMITTER OIL LEVEL	ACC	GTCP331	Various	FT
Triumph Air Repair	3876084-1	TRANSDUCER TOTAL PRESSURE	ACC	GTCP331	Various	FT
Triumph Air Repair	3876085-2	TRANSDUCER DELTA P	ACC	GTCP331	Various	FT
Triumph Air Repair	3876085-3	TRANSDUCER DELTA P	ACC	GTCP331	Various	FT
Triumph Air Repair	3876085-4	TRANSDUCER DELTA P	ACC	GTCP331	Various	FT
Triumph Air Repair	3876086-2	HOUSING FLOW SENSOR	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3876166-1	VALVE DE-OIL SOLENOID	ACC	GTCP331	Various	FT
Triumph Air Repair	3880190-10	PUMP ASSEMBLY LUBE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3880190-5	PUMP ASSEMBLY LUBE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3880190-8	PUMP ASSEMBLY LUBE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3880200-3	PUMP ASSEMBLY GENERATOR SCAVENGE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3880200-4	PUMP ASSEMBLY GENERATOR SCAVENGE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3880200-5	PUMP ASSEMBLY GENERATOR SCAVENGE	ACC	GTCP331	Various	Overhaul

Triumph Air Repair	3880200-6	PUMP ASSEMBLY GENERATOR SCAVENGE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3882500-12	FUEL CONTROL UNIT	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3882500-14	FUEL CONTROL UNIT	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3882500-16	FUEL CONTROL UNIT	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3882500-17	FUEL CONTROL UNIT	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3882506-6	TORQUE MOTOR FUEL CONT	ACC	GTCP331	Various	FT
Triumph Air Repair	3882550-3	VALVE ASSY FLOW	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3886070-4	ACTUATOR IGV	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3886167-3	ACTUATOR IGV	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3888058-5	EXCITER	ACC	GTCP331	Various	FT
Triumph Air Repair	397728-6-1	VALVE FAN SHUTOFF	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	3F14879-501	THERMOCOUPLE	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	519858-6	STARTER ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	519858-7	STARTER ASSY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	519858-8	STARTER ASSEMBLY	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	727810B	GENERATOR (331)	ACC	GTCP331	Various	I
Triumph Air Repair	727810C	GENERATOR (331)	ACC	GTCP331	Various	I
Triumph Air Repair	8TJ99GGE1	TRANSMITTER LIQUID QUANTITY	ACC	GTCP331	Various	FT
Triumph Air Repair	968214-6	VALVE ASSY PRESS RELIEF	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	969249-5	COOLING FAN	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	979786-2	VALVE LOAD	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	979806-10	VALVE SURGE CONTROL	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	979806-11	VALVE SURGE CONTROL	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	979806-9	VALVE SURGE CONTROL	ACC	GTCP331	Various	Overhaul
Triumph Air Repair	MS28034-3	BULB OIL TEMP	ACC	GTCP331	Various	FT
Triumph Air Repair	109630-3-1	VALVE LOAD CONTROL	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	109630-7-1	VALVE LOAD CONTROL	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	109820-10-1	VALVE SURGE BLEED	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	157790-6	COOLER AIR TO OIL	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	2100906-021	CONTROL ELEC TURB	ACC	GTCP660	B747	I
Triumph Air Repair	28B263-13B	GENERATOR ASSEMBLY	ACC	GTCP660	B747	I
Triumph Air Repair	305680-1	HARNESS ASSEMBLY EGT THERMOCOUPLE	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	305680-2	HARNESS ASSEMBLY EGT THERMOCOUPLE	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	305681-1	THERMOCOUPLE	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	306890-1	SENSOR LIQUID LEVEL FLOAT	ACC	GTCP660	B747	FT
Triumph Air Repair	306890-3	SENSOR LIQUID LEVEL FLOAT	ACC	GTCP660	B747	FT
Triumph Air Repair	3600234-1	DIFFERENTIAL PRESSURE	ACC	GTCP660	B747	Overhaul

Triumph Air Repair	3603715-2	VALVE ASSY REGULATOR	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3603879-1-1	METERING VALVE AND FLOW DIVIDER ASSY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3603879-2-1	METERING VALVE AND FLOW DIVIDER ASSY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604438-1	NOZZLE AND MANIFOLD ASSEMBLY PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604438-2	NOZZLE AND MANIFOLD ASSEMBLY PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604438-3	NOZZLE AND MANIFOLD ASSEMBLY PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604557-1	NOZZLE AND MANIFOLD ASSEMBLY SECONDARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604557-2	NOZZLE AND MANIFOLD ASSEMBLY SECONDARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604557-3	NOZZLE AND MANIFOLD ASSEMBLY SECONDARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3604557-5	NOZZLE AND MANIFOLD ASSEMBLY SECONDARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3606212-1	MANIFOLD FUEL PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	3608999-1	VALVE BLEED	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	397728-1-1	VALVE FAN SHUTOFF	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	397728-3-1	VALVE FAN SHUTOFF	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	43877-2	HARNESS ASSEMBLY WIRING	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	43877-3	HARNESS ASSEMBLY WIRING	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	43877-4	HARNESS ASSEMBLY WIRING	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	43877-5	HARNESS ASSEMBLY WIRING	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	519802-2	STARTER MOTOR	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	519806-2	STARTER ASSY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	519806-3	STARTER ASSY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	899727-10	FUEL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	899727-3-1	FUEL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	899727-5-1	FUEL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	899727-9-1	FUEL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	949848-8	MODULE FAULT INDICATION	ACC	GTCP660	B747	I
Triumph Air Repair	968874-3	OIL COOLER ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968034-1	IGNITION UNIT	ACC	GTCP660	B747	FT
Triumph Air Repair	968348-2	OIL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968348-3	OIL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968348-4	OIL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968348-5	OIL PUMP ASSEMBLY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968582-2	MANIFOLD FUEL PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968582-3	MANIFOLD FUEL PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968604-4	NOZZLE ASSEMBLY PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968604-5	NOZZLE ASSEMBLY PRIMARY	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	968874-2	COOLER ASSEMBLY OIL	ACC	GTCP660	B747	Overhaul

Triumph Air Repair	968874-3	COOLER ASSEMBLY OIL	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	976014-1	SENSOR AIR FLOW	ACC	GTCP660	B747	I
Triumph Air Repair	976014-2	SENSOR AIR FLOW	ACC	GTCP660	B747	I
Triumph Air Repair	978602-1-1	VALVE SHUTOFF	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	978602-2-1	VALVE SHUTOFF	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	978602-3-1	VALVE SHUTOFF	ACC	GTCP660	B747	Overhaul
Triumph Air Repair	10-387125-2	EXCITER IGNITION	ACC	TSCP700	Various	FT
Triumph Air Repair	109612-3	VALVE BLEED LOAD	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	109700-5	VALVE PRESSURE REGULATING	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	109700-6	VALVE PRESSURE REGULATING	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	109700-7	VALVE PRESSURE REGULATING	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	2700187M2	ACTUATOR VTN HYDRAULIC	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3290406-2	VALVE	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3600023-1	THERMOCOUPLE IMMERSION	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3600232-2	ACTUATOR VTN HYDRAULIC	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3601170-4	SENSOR SPEED	ACC	TSCP700	Various	FT
Triumph Air Repair	3601170-5	SENSOR SPEED	ACC	TSCP700	Various	FT
Triumph Air Repair	3601834-2	VALVE SOLENOID	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3602883-5	FAN ASSY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3603357-1	STARTER ASSEMBLY ELECTRIC	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3603357-3	STARTER ASSEMBLY ELECTRIC	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3603540-2	SWITCH DIFF PRESS	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3603540-3	SWITCH DIFF PRESS	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3603715-4	VALVE ASSEMBLY REGULATOR	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3603756-4	SENSOR SPEED	ACC	TSCP700	Various	FT
Triumph Air Repair	3790076-103	ACTUATOR VTN	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3876027-3	THERMOCOUPLE EGT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3876047-4	VALVE DE-OIL SOLENOID	ACC	TSCP700	Various	FT
Triumph Air Repair	3880998-1	OIL PUMP	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3882550-1	VALVE ASSY FLOW	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3882550-2	VALVE ASSY FLOW	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3882883-1	VALVE ASSY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3883229-4	FUEL CONTROL ASSY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3883229-5	FUEL CONTROL ASSY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3883236-1	VALVE DELTA P	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	3883277-1	VALVE ASSEMBLY FUEL FLOW DIVIDER	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	4140066-8	SOLENOID VALVE	ACC	TSCP700	Various	FT

Triumph Air Repair	43893-3	HARNESS WIRING	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	519804-9	STARTER ASSY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	519852-2	STARTER ASSY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	892987-3	NOZZLE FUEL	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	892987-7	NOZZLE FUEL	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-10	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-11	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-12	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-13	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-14	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-8	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	969900-9	FUEL CONTROL UNIT	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	977968-12	FUEL MANIFOLD PRIMARY	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	979806-5-1	VALVE SURGE CONTROL	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	979806-6-1	VALVE SURGE CONTROL	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	979806-7	VALVE SURGE CONTROL	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	979806-8	VALVE SURGE CONTROL	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	A64847-5	ACTUATOR VTN	ACC	TSCP700	Various	Overhaul
Triumph Air Repair	10-381160-2	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381175-1	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381175-2	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381175-3	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381175-4	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381175-6	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381175-9	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381200-2	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381200-7	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381750-1	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381750-10	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381750-5	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-381750-6	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10-397050-1	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	10169	TRANSFORMER	ACC	GTCP85	Various	FT
Triumph Air Repair	1051T100-11	ACTUATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	1051T100-13	ACTUATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	1051T100-19	ACTUATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	1051T100-9	ACTUATOR	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	107996	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-1-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-10-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-11-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-12-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-16	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-22-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-23-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-24-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-28-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-3-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-31-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-33-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-34-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-36-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-39-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-4-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-50-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-53-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-56-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-57-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-58-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-59-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-61-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-66-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-67-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-68-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-72-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-75-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-77-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-78-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	107996-8-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-0-3	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-0-39	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-10	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-10-1	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-3	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	108032-6	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-6-1	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-8	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-9	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	108032-9-1	REGULATOR AIR PRESSURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109016-10-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-11-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-13-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-17-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-25-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-26-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-28-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-31-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-32-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-35-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109382-7-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109486-1-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109486-4-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109486-5-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109486-6-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109644-1-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109644-2-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109644-3-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109644-6-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109710-2-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	109710-6-1	VALVE LOAD CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	122100	VALVE SURGE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-10-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-11	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-18	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-19	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-19-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-2-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-20-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-23	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-23-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-32	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	124536-34-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-38	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124536-5-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124750-3-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124750-4-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	124750-8	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	129224-50-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	129224-53-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	129552-1-1	THERMOSTAT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	152050-3-1	OIL COOLER ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	152050-4-1	OIL COOLER ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	152050-5-1	OIL COOLER ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	1564T100-9	ACTUATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	204050-10	TURBINE COOLING	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	204950-5-4	TURBINE COOLING	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	23046-015	STARTER/GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	2CM9ABY7	TACH GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	30293-1	PUMP FUEL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	307130-1-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	32005	TACH GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	320362-2-1	VALVE 3 WAY SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	320362-3-1	VALVE 3 WAY SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	32164-000	TACHOMETER GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	32164-005	TACHOMETER GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	32164-007	TACHOMETER GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	32164-010	TACHOMETER GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	32164-012	TACHOMETER GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	32164-015	TACHOMETER GENERATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-1-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-10	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-10-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-11	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-11-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-13	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-13-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-2-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	3601030-3-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-5	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-5-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-6-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601030-9-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601193-1	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601193-2	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601193-3	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601193-4	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601193-5	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601193-6	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3601356-9-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602043-2-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-10-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-13	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-14	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-15-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-16	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-17-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-2	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-2-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-22	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-24	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-24-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-27	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-28-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-29	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-3	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-3-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-30	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-32	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-32-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-33	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-33-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-36	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-37	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	3602310-4-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-5-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3602310-7	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603100-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603100-2-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603100-4	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603100-6	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603100-6-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603100-7	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603281-2	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	3603281-3	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	3603281-4	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	3603281-5	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	3603281-6	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	3603511-1-1	GEARBOX	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603701-1	GEARCASE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3603701-3	GEARCASE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604174-1-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-1	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-11	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-14	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-19	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-2	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-22	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-23	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-25	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-26	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-27	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-29	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-3	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-4	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-45	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-46	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-47	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-6	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-7	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3604524-9	COMBUSTOR ASSY	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	3605239-2	VALVE PROPORTIONAL CONTROL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-10	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-13	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-14	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-14-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-16	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-16-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-17	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-17-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-19-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-2	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-21-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-22	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-22-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-3	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3605812-4	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3608000-10	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3608000-4	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3608000-6	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-1-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-2	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-2-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-3	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-3-1	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609150-5	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-1	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-10	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-11	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-13	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-2	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-3	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-5	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-5-1	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-6	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3609480-9	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	3615700-13	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3615700-5	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-13	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-15	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-20	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-22	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-3	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-32	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	369259-7	IGNITION LEAD	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	370247	VALVE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	370929-12	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	370929-14	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	370929-19	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	371688-10	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	371688-101	FUEL CONTROL UNIT	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	371976-14	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	371976-18	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-1-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-10	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-16	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-18-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-21	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-21-1	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-24	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-6	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	372697-9	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373027-2	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373048-1	VALVE ASSY OIL CRISSAIR ONLY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373048-3	VALVE ASSY OIL CRISSAIR ONLY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373205-2	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373574-3	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373574-4	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373574-5	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	373574-5-1	SWITCH ASSY CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375036	SWITCH OIL TEMPERATURE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375322-10	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375322-7	STARTER	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	375322-8	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375322-9	STARTER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375324-2	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375324-3	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	375645-33	GEARBOX	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	377869	EXCITER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-150	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-200	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-300	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-350	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-600	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-650	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	379580-700	PUMP OIL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3880160-2	PUMP OIL SCAVENGE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3883998-1	FLOW DIVIDER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3883998-2	FLOW DIVIDER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3888134-1	VALVE SOLENOID	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3924624-1	HARNESS GEN	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	392824-1-1	VALVE PRESSURE REGULATOR	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	397868-1	VALVE ANTI-SURGE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	397868-1-1	VALVE ANTI-SURGE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	43888-3	HARNESS WIRING	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	43933-7	HARNESS WIRING	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	43964-1	HARNESS WIRING	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	43973-3	HARNESS WIRING	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	45905-1	VALVE SOLENOID	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	5916083-501	DOOR QEC DEMOUNTABLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	5916083-509	DOOR DC-9 Q.E.C.	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	5916083-527	DOOR DC-9 QEC	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	5916333-1	DOOR DC-9 Q.E.C.	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	5916333-501	DOOR DC-9 Q.E.C.	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	5917241-1	VALVE ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	61-20136-002	WIRE BUNDLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	61-20136-010	WIRE BUNDLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	61-30100-002	WIRE BUNDLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	65C15332-1	VALVE ASSY COCOON	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	65C15335-1	VALVE ASSY COCOON	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	692523	THERMOCOUPLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	692523-1	THERMOCOUPLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	692523-2	THERMOCOUPLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	692523-8	THERMOCOUPLE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	692525	SWITCH OIL SEQ	ACC	GTCP85	Various	FT
Triumph Air Repair	692525-7	SWITCH OIL SEQ	ACC	GTCP85	Various	FT
Triumph Air Repair	692525-9	SWITCH OIL SEQ	ACC	GTCP85	Various	FT
Triumph Air Repair	692545	VALVE SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	692545-1	VALVE SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	692545-2	VALVE SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	692545-3	VALVE SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	692546-2	VALVE SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	692993	VALVE SOLENOID OVERSPEED	ACC	GTCP85	Various	FT
Triumph Air Repair	693657-5	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	693657-8	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-10	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-11	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-12	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-15	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-16	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-22	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-23	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-24	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	695227-25	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	696010-22-1	CONTROL UNIT FUEL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-11	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-13	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-14	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-14-1	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-15	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-16	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-18	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-4	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-7	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-8	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	698427-9	FAN ASSY	ACC	GTCP85	Various	Overhaul

Triumph Air Repair	698430-1	SWITCH L.O.P.	ACC	GTCP85	Various	FT
Triumph Air Repair	698430-2	SWITCH OIL SEQ	ACC	GTCP85	Various	FT
Triumph Air Repair	698480-1	SWITCH	ACC	GTCP85	Various	FT
Triumph Air Repair	698788-2	METER HOUR	ACC	GTCP85	Various	FT
Triumph Air Repair	75076-18	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	75076-22	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	75076-26	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	75076-32	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	75076-39	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	76067-13	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899222-1	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899357-8	FAN ASSY	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899580-1	EXCITER	ACC	GTCP85	Various	FT
Triumph Air Repair	899981-1	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-10	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-2	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-3	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-5	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-6	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-7	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	899981-9	ATOMIZER	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	948894-2-2	CONTROL OVERTEMP	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	948894-4-1	SWITCH OIL TEMPERATURE	ACC	GTCP85	Various	FT
Triumph Air Repair	948894-5	CONTROL OVERTEMP	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	976087-1	VALVE 2 WAY SOLENOID	ACC	GTCP85	Various	FT
Triumph Air Repair	976150-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	976150-1-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	976150-2	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	976150-2-1	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	976150-5	SWITCH CENTRIFUGAL	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	976J119-12	GENERATOR	ACC	GTCP85	Various	R
Triumph Air Repair	976J119-8	GENERATOR	ACC	GTCP85	Various	R
Triumph Air Repair	977355-1	VALVE	ACC	GTCP85	Various	Overhaul
Triumph Air Repair	3888449-1	HARNES	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	3291214-2	VALVE, BLEED AIR	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	441921-4	FUEL CONTROL	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	3883600-2	FUEL CONTROL	ACC	GTCP131	Various	Overhaul

Triumph Air Repair	3888448-1	HARNESS	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	3886188-2	ACTUATOR, INLET GUIDE VANE	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	4131010-2	PUMP ASSEMBLY	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	4131020-3	LUBE MODULE	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	4131020-4	LUBE MODULE	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	160564-1	OIL COOLER	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	109854-3	VALVE, SURGE CONTROL	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	109854-4	VALVE, SURGE CONTROL	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	3291238-2	VALVE, SURGE CONTROL	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	160550-1	VALVE, TEMP CONTROL	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	3291432-1	VALVE, LOAD CONTROL	ACC	GTCP131	Various	Overhaul
Triumph Air Repair	28B545-5	STARTER-GENERTAOR	ACC	GTCP131	Various	FT
Triumph Air Repair	3900277	VALVE BYPASS, THERMOSTATIC	ACC	PW901	B747	FT
Triumph Air Repair	3900372	VALVE BYPASS, THERMOSTATIC	ACC	PW901	B747	FT
Triumph Air Repair	3900065	SPEED SENSOR GEARBOX	ACC	PW901	B747	FT
Triumph Air Repair	3911033-01	SPEED SENSOR LOAD COMP.	ACC	PW901	B747	FT
Triumph Air Repair	3911404-01	SPEED SENSOR LOAD COMP.	ACC	PW901	B747	FT
Triumph Air Repair	3900060	AIR PRESSURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900060	AIR PRESSURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900391	AIR PRESSURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3912151-01	AIR PRESSURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900067	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900061	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900269	OIL PRESSURE SWITCH	ACC	PW901	B747	FT
Triumph Air Repair	3900451	OIL PRESSURE SWITCH	ACC	PW901	B747	FT
Triumph Air Repair	3900459	OIL PRESSURE SWITCH	ACC	PW901	B747	FT
Triumph Air Repair	3900657	OIL PRESSURE SWITCH	ACC	PW901	B747	FT
Triumph Air Repair	3900062	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900392	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3912233-01	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900062	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900392	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3912233-01	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	39101906-01	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900063	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3900456	TEMPERATURE SENSOR	ACC	PW901	B747	FT
Triumph Air Repair	3912159-01	TEMPERATURE SENSOR	ACC	PW901	B747	FT

Triumph Air Repair	RFN12A	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3910066-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3911331-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3900465	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3911987-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	01R3911987-0	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3911987-02	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3910067-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3911330-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3900466	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3911988-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	01R3911988-0	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	02R3911988-0	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	03R3911988-0	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3911988-02	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912235-01	WIRING HARNESS FRONT	ACC	PW901	B747	Overhaul
Triumph Air Repair	3910068-01	THERMOCOUPLE	ACC	PW901	B747	FT
Triumph Air Repair	3911290-01	THERMOCOUPLE	ACC	PW901	B747	FT
Triumph Air Repair	3911385-01	THERMOCOUPLE	ACC	PW901	B747	FT
Triumph Air Repair	3912158-01	THERMOCOUPLE	ACC	PW901	B747	FT
Triumph Air Repair	3900058	TRIM BOX THERMOCOUPLE	ACC	PW901	B747	FT
Triumph Air Repair	3900057	IDENTIFICATION UNIT	ACC	PW901	B747	FT
Triumph Air Repair	C5116-08	ELECTRIC STARTER	ACC	PW901	B747	Overhaul
Triumph Air Repair	C5116-10	ELECTRIC STARTER	ACC	PW901	B747	Overhaul
Triumph Air Repair	C5116-11	ELECTRIC STARTER	ACC	PW901	B747	Overhaul
Triumph Air Repair	26030	FLOW DIVIDER DUMP VALVE	ACC	PW901	B747	Overhaul
Triumph Air Repair	26375-1	FLOW DIVIDER DUMP VALVE	ACC	PW901	B747	Overhaul
Triumph Air Repair	26375-2	FLOW DIVIDER DUMP VALVE	ACC	PW901	B747	Overhaul
Triumph Air Repair	715201-	FUEL PUMP	ACC	PW901	B747	Overhaul
Triumph Air Repair	3910834	OIL PUMP	ACC	PW901	B747	Overhaul
Triumph Air Repair	3910870	OIL PUMP	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912040	OIL PUMP	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912024	OIL PUMP	ACC	PW901	B747	Overhaul
Triumph Air Repair	D1979-200A	OIL COOLER	ACC	PW901	B747	FT
Triumph Air Repair	D2045-300A	FUEL COOLED OIL COOLER	ACC	PW901	B747	FT
Triumph Air Repair	3910553	OIL PRESS. REGULATOR	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912083	OIL PRESS. REGULATOR	ACC	PW901	B747	Overhaul

Triumph Air Repair	800956	DIVERTER VALVE	ACC	PW901	B747	Overhaul
Triumph Air Repair	800953-1	ACTUATOR, INLET GUIDE VANE	ACC	PW901	B747	FT
Triumph Air Repair	800953-1L2	ACTUATOR, INLET GUIDE VANE	ACC	PW901	B747	FT
Triumph Air Repair	800953-1L3	ACTUATOR, INLET GUIDE VANE	ACC	PW901	B747	FT
Triumph Air Repair	800955-1	RATE SENSOR	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912063-01	COOLING FAN	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912063-04	COOLING FAN	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912063-05	COOLING FAN	ACC	PW901	B747	Overhaul
Triumph Air Repair	3912225-01	COOLING FAN	ACC	PW901	B747	Overhaul